


SERVICE



Instruction manual

SV100/E





GLASS DRYER

CONTENTS

A	GENERAL INFORMATION.....	Page 2
A1	PRODUCT DESCRIPTION	Page 3
A2	TECHNICAL INFORMATION.....	Page 3
A3	TRANSPORTATION	Page 4
A4	UNPACKING	Page 4
B	INSTALLATION	Page 4
C	SAFETY INSTRUCTIONS	Page 5
D	OPERATION	Page 6
E	CLEANING & MAINTENANCE.....	Page 7
F	TROUBLESHOOTING	Page 8
G	SPARE PART LIST- EXPLODING DRAWING	Page 9
H	ELECTRIC CIRCUIT SCHEMA	Page 13

A GENERAL INFORMATION

Before installing the appliance, read operation and maintenance instructions carefully. Wrong installation and part changing may damage the product or may cause injury on people. These are not in our company's responsibility to damage the appliance intentionally, negligence, detriments because of disobeying instructions and regulations, wrong connections. Unauthorized intervention to appliance invalidates the warranty.

1. This instruction manual should be kept in a safe place for future reference.
2. **Installation should be made in accordance with ordinances and security rules of that country by a qualified service personnel.**
3. This appliance has to be used by trained person.
4. Please turn off the appliance immediately in the event of malfunction or failure. The appliance should be repaired only by authorized service personnel. Please demand original spare part.

GLASS DRYER

A1 PRODUCT DESCRIPTION

*The Professional Glasswasher ,that provides high efficiency has been designed to be used in industrial kitchens.

Product Code	Dimensions (mm)	Weight (kg)	Packaging Dimensions (mm)
EMP.BPR.001	355x595x505	27	680x360x570
SV100/E	325x370x505	20	380x360x570

A2 TECHNICAL INFORMATION

Product Code	Capacity (glass/hour)	Motor Power (KW)	Total Power (Kw)	Operating Voltage (V)	Cable (mm²)	Fuse (A)
EMP.BPR.001	600-720	0,37	2,6	220-240	3x1,5	16
SV100/E	300-360	0,37	1,5	220-240	3x1,5	10

A3 TRANSPORTATION

*This appliance can be moved by hand from area to area. Do not crash and drop the appliance while transporting.

A4 UNPACKING

*Please unpack the package according to the security codes and ordinances of current country and get rid from the pack. Parts which contacts with food are produced by stainless steel. All plastic parts are marked by material's symbol.

*Please check that all the parts of appliance had come completely and if they are damaged or not during the shipping.

B INSTALLATION

*Please place the product to straight and sturdy ground, please take necessary steps against possibility of overturn.

*Technician who will serve for installation and service for the appliance must be professional on this subject and must have installation and service licenses by the company.

*Connection to Electric Power Supply must be done by authorized person.

*Please be sure that the voltage connected to appliance must be equal with the voltage which is on appliance's label.



This appliance must be connected to an earthed outlet in accordance with safety rules and standards.

*Appliance's earthing must be connected to earthing line on panel which is nearest to electric installation.

*Connection to the main fuse and leak current fuse must be done in accordance with the current regulations.

GLASS DRYER

C SAFETY INSTRUCTIONS



*Do not use the appliance in insufficient lighted place.



*Do not touch the moving attachments while the appliance operates.



*Do not install the appliance in the presence of flammable or explosive materials.



*Do not operate the appliance when the machine is empty.



*Do not load so less or more than appliance's capacity.



*Do not attempt to use the appliance without suitable protective equipments.




*Because of any reason if there is a fire or flame flare where the appliance is used, turn off all gas valves and electric contactor switch quickly and use fire extinguisher. Never use water to extinguish the fire.



*All the damages because of not having earthing connection will not be on warranty.

D OPERATION

*Control Panel;



A : OFF
B : ON
C : FUSE

*Operating;

- Plug in the appliance.
- In order to operate the appliance switch to START position.
- After the tassels start to turn, place the glasses on the tassels one by one.
- Take off the glasses that are dried by hot air blowing resistances.
- Repeat this process in periodic times.
- After operation is completed switch to STOP position and unplug the appliance.

GLASS DRYER

E CLEANING & MAINTENANCE

➤ **CLEANING AND MAINTENANCE AFTER EVERY USE**

- Always turn off the appliance and disconnect from the power supply before cleaning.
- Clean all the surfaces of the appliance with a moist cloth and then dry after every use.
- Perform the washing process with water that is not hotter than 60°C
- Do not use abrasive cleaning chemicals as these can leave harmful residues.
- Do not clean the appliance by spraying water directly, otherwise electric motor may get damaged.

➤ **PERIODIC CLEANING AND MAINTENANCE**

- Maintenance should be done by qualified person.
- Get the periodic maintenance of the appliance once in every 15 days.
- Check the tassels according to frequency of use. If there is excessive deformation, change it.
- Check the resistances in periodic times.
- The Glass Drying Machines require low maintenance (Motor and ball bearings are lubricated).
- Check the motor and tension of the belt.

F TROUBLESHOOTING

THE APPLIANCE DOESN'T OPERATE	1. Check if the appliance is plugged in. 2. Check the electrical connections and voltage. 3. Check the fuse if it is on or not.
--------------------------------------	---

THE GLASSES ARE NOT DRIED	1. Check the tassels. 2. Check the hot air resistances.
----------------------------------	--


THE APPLIANCE STOPPED	1. The appliance can stop due to low voltage. In this situation check the voltage. 2. The fuse that doesn't have enough Amper is broken. In this situation place a new fuse.
------------------------------	---

- If glass drying is not done at suitable quality
- If any function of security doesn't work
 - Do not use the appliance.

***If these problems are still going on, contact with our authorized services.**

GLASS DRYER

G SPARE PART LIST-EXPLODING DRAWING




EMP.BPR.001

G SPARE PART LIST-EXPLODING DRAWING

PRODUCT CODE: EMP.BPR.001		
NO	PRODUCT NAME	P.CODE
1	TOP COVER	M.MTS-ERS-BPR-001
2	TASSEL	ARA.FS-BPR-KISA
3	SHORT MILES	YTL-ERS.BPR-KS-0004
4	ORING	ERS.M.CNT-ORG-001
5	M6*10 SCREW	B-MVC-GLV-SET-M6*10
6	STRAP (8*400)	M.KYS-VKY-001
7	STRAP (8*450)	M.KYS-VKY-002
8	PIPE COVER	YSC-ERS.BPR-LZ-0007
9	DRYING PIPE	YBR-ERS.BPR-KS-0003
10	DRYING CONNECTION SHEET	YSC-ERS.BPR-LZ-0006
11	FAN	M.ELK-HVL-SFN-001
12	ENGINE (ENGINE)	M.ELK-MTR-RLM-001
13	ENGINE SHAFT	YTL-ERS.BPR-KS-0002
14	ENGINE PULLEY	YTL-ERS.BPR-KS-0007
15	CHASSIS	-
16	PG-9 CABLE FITTING	ERS.M.ELK-RKR-PLS-002
17	1100W-220V RESISTANCE	ERS.M.ELK-RZS-OZL-001
18	GLASS FUSE 15 A	ERS.M.ELK-SGR-003
19	INSURANCE	ERS.M.MUH-010
20	GREEN LIGHT SWITCH	ERS.M.ELK-SLT-ANL-002
21	WIRING HARNESS GROUP	M.ELK-KD-BPR-001
22	CONTACTOR	ERS.M.ELK-KNT-KNT-010
23	SCREW PIN	YTL-ERS.BPR-KS-0001
24	BEARING (6202 2RS)	M.RLM-NRM-003
25	SLEEVE PULLEY	YTL-ERS.BPR-KS-0006
26	LONG MILES	YTL-ERS.BPR-KS-0003
27	TASSEL	ARA.FS-BPR-UZUN

GLASS DRYER

G SPARE PART LIST-EXPLODING DRAWING




G SPARE PART LIST-EXPLODING DRAWING

PRODUCT CODE: SV100/E		
NO	PRODUCT NAME	P.CODE
1	TOP COVER	M.MTS-ERS-BPR-002
2	TASSEL	ARA.FS-BPR-KISA
3	ORING	ERS.M.CNT-ORG-001
4	M6*10 SCREW	B-MVC-GLV-SET-M6*10
5	SCREW PIN	YTL-ERS.BPR-KS-0001
6	STRAP (8*400)	M.KYS-VKY-001
7	STRAP (8*450)	M.KYS-VKY-002
8	CHASSIS	-
9	PIPE COVER	YSC-ERS.BPR-LZ-0007
10	DRYING PIPE	YBR-ERS.BPR-KS-0003
11	DRYING CONNECTION SHEET	YSC-ERS.BPR-LZ-0006
12	FAN	M.ELK-HVL-SFN-001
13	ENGINE (ENGINE)	M.ELK-MTR-RLM-001
14	ENGINE SHAFT	YTL-ERS.BPR-KS-0002
15	ENGINE PULLEY	YTL-ERS.BPR-KS-0007
16	FOOT	ERS.M.AKS-AYK-PLS-002
17	1100W-220V RESISTANCE	ERS.M.ELK-RZS-OZL-001
18	GLASS FUSE 15 A	ERS.M.ELK-SGR-003
19	INSURANCE	ERS.M.MUH-010
20	GREEN LIGHT SWITCH	ERS.M.ELK-SLT-ANL-002
21	WIRING HARNESS GROUP	M.ELK-KD-BPR-002
22	CONTACTOR	ERS.M.ELK-KNT-KNT-010
23	BEARING (6202 2RS)	M.RLM-NRM-003
24	SLEEVE PULLEY	YTL-ERS.BPR-KS-0006
25	SHORT MILES	YTL-ERS.BPR-KS-0004
26	LONG MILES	YTL-ERS.BPR-KS-0003
27	TASSEL	ARA.FS-BPR-UZUN

GLASS DRYER


H ELECTRIC CIRCUIT SCHEMA



EMP.BPR.001

M	A1	F	R1	R2	FN.1	FN.2
Motor 0,18 KW 2800 rpm 220V	Large lighted 0-1 Switch	Fuse 15A	Right Resistance 1000W	Left Resistance 1000W	Right Fan Motor 90 W 2400 rpm	Left Fan Motor 90 W 2400 rpm

H ELECTRIC CIRCUIT SCHEMA



M	A1	F	R1	FN.1
Motor 0,18KW 2800 rpm 220 V	Large lighted 0-1 Switch	Fuse 15A	Right Resistance 1000W	Right Fan Motor 90 W 2400 rpm