


SERVICE



Exploded view

AQZ0001/E





NO	SPARE PART NAME	STOCK CODE
1	BASE FRAME	Y.EMP.WF.010.001
2	TOP LID	Y.EMP.WF.010.002
3	INNER FRAME	Y.EMP.WF.010.003
4	RESISTANCE HOLDER (TOP)	Y.EMP.WF.010.004
5	RESISTANCE HOLDER (BOTTOM)	Y.EMP.WF.010.005
6	AIR CONDITIONING GRILL-BOTTOM	Y.EMP.WF.010.006
7	CONTROL PANEL	Y.EMP.WF.010.007
8	DOUGH FLOWING DIVISION (BACK)	Y.EMP.WF.010.008
9	DOUGH FLOWING DIVISION	Y.EMP.WF.010.009
10	SPATULA	Y.EMP.WF.010.010
11	BOTTOM CASTING	Y.EMP.WF.010.011
12	TOP CASTING	Y.EMP.WF.010.012
13	LID HANDLE	Y.EMP.WF.010.013
14	LID HANDLE	Y.EMP.WF.010.014
15	SWITCH	Y.EMP.WF.010.015
16	THERMOSTAT	Y.EMP.WF.010.016
17	SWITCH BUTTON	Y.EMP.WF.010.017
18	THERMOSTAT BUTTON	Y.EMP.WF.010.018
19	LED	Y.EMP.WF.010.019
20	TOP RESISTANCE	Y.EMP.WF.010.020
21	BOTTOM RESISITANCE	Y.EMP.WF.010.021
22	FEET	Y.EMP.WF.010.022