


SERVICE



Wiring diagram

ICE0010 | ICE0011 | ICE0012 | ICE0013





A1	L1	R1
(0-1) position switch	Switch signal lamp	Resistance 1000W